



T8 Fingerprint Machine
Hardware User Manual

Date: 2010.03.18
Version: 1.1



Table of Content

Introduction.....	3
Installation.....	3
Menu Structure.....	6
User Management	6
Device Management	6
U Disk Management	7
Sys Info	7
Alarm Reset	7
Startup Screen	7
User Management	8
Device Management	9
Basic Setting	9
Advance Setting	10
Schedule Setting.....	12
Log Setting.....	12
Comm Setting	13
Door Access Setting	15
Auto Checking	19
USB Disk Management	19
Download Enroll Data	19
Download Management Record	19
Download User Information	19
Upload User Information	19
Upload Message Transfer	19
Upload MP3	19
Sys Info	19
Memory.....	20
Device Information	21
Advanced Inquiry.....	21
Alarm reset.....	22

Introduction


This manual is to teach user the internal structure of T8 and the using of this fingerprint machine. T8 is a color display time attendance and door access control fingerprint machine. Its outlook is very attractive.

It is an online fingerprint device which allows you to download data from it in online mode. You may also choose to download it by offline mode. Besides, it can be used for door access with full functional time zone management.


Installation

We used to install T8 in the wall. It is because it can avoid strong light shining on the fingerprint optical sensor. It will seriously affect the recognition ability of the fingerprint device.

Normally, we will mount the device to the wall in about 1.4 meters high.




Electric Lock and Alarm Connection





The back of the fingerprint device has a metal rack which can be used to mount the fingerprint device to the wall.

Communication terminal and power supply




Metal rack





Screw for fixing the rack to the device

USB device & SD card connection



USB slot for USB flash disk and USB CAM

SD card slot

Cable outlet

Menu Structure

The menu structure of T8 is as follows

User Management

- Fingerprint enroll
- RF Card enroll
- Password enroll
- Sound recording
- Photo making

Device Management

- Basic Setting
- Advance Setting
- Schedule Setting
- Comm Setting
- Alert Setting
- Door Access Setting
- Self Checking

U Disk Management

- Download enroll record
- Download management record
- Download user information
- Upload user information
- Upload message transfer
- Upload MP3

Sys Info


- Memory
- Device Info
- Advanced

Alarm Reset

Startup Screen

When you switch on the machine, a logo will be shown for 3 seconds. The logo is a bitmap of dimension 320 * 240 pixels. OEM customer can put their bitmap into the machine to show their company name.

After the logo, you can see a loading screen which shows the process of loading all the components for the running of the machine. The bottom status bar show the progress of the loading. When the bottom dark blue bar reaches the end, this screen will be disappeared.



A waiting screen will be displayed instead. The waiting screen will show the current date and time. Also, a graph of clock is in left side. If you have set the time status, it will display it too. Time status is to define the different period of time for different status. Examples are Duty On or Duty Off.




When the machine is idle for 10 minutes, screen saver will be invoked. The screen saver consists of 3 pictures. They will be displayed alternatively. Besides, you can hear a short song for relaxation of the environment.

In the screen saver mode, you can also punch fingerprint or press the “menu” button to access different menu items.

User Management

In user management, you can add a new user or delete an existing user.



Each user has a unique user ID. When you add a new user, you need to input a user ID first. The last unused user ID will be shown. If you accept it, you just press <ok>. If not, you can use numeric button to input the specified user ID. The preceding zero is not needed. If you want to input 27, just press button “2” and “7” only.

After that, you need to select which verification to register. You can select fingerprint, card or password. Card is optional.





If you select fingerprint, you need to enroll fingerprint 3 times. The machine will get the best fingerprint template and store it as a comparing standard.

If you choose card, you need to punch a card to replace the input of card number.

If you choose password, you need to input the password by the numeric keypad

After Registration

If you choose voice, you need to insert SD card first before recording to store voice record. (not support SDHC) All the voice record will be saved in SD card.



To delete a user, you just input the user ID for deletion.

Before enrollment, we used to have a list of user ID and staff for reference.

User ID	Staff Number	Name
1	MIS001	John
2	ACC001	Mary
3	MIS002	Peter
4	SAL001	Susan

Device Management

Device management is divided into 7 sub menus. They are basic setting, advance setting, power management, communication management, record management, door access management and auto check. Each sub menu has a list of menu items for different argument setting. Use left and right, up and down arrow and go to different menu items.

Basic Setting

Basic setting is the elementary setting of the device. It includes the setting of time, voice, language, loudness adjustment and button sound.

Time Setting

Time setting is used to set the device and time of the device. After a period of time, the device time may be varied from the actual time. Using this menu item can correct the time. The Pegasus software will synchronize the time of the device when you download data. It guarantees the accuracy of each device when there are many devices in a network.

Language Setting

You can also set the language of the device. The default language allowed are English, Traditional Chinese and Simplified Chinese. Customer can request for making another language such as Thailand or Spanish.

Voice Setting

Voice out on/off is to set the response of the device. When you punch the device correctly, the device will speak 'thank you'. If the fingerprint has not been enrolled or the identification fails, the device will speak 'press again!'. If you off the voice out item, the device will not say anything.

When the punch is authorized, it will just give 3 short beep sounds. If it fails, it will give a long beep sound and the display will show "Press again".

The voice is located in a sound chip in the main board. The sound chip can only store one language of voice. So, before leaving the factory, customer need to specify which language of voice they need.

Loudness Adjustment

It is to adjust the loudness of the voice if you have switch on the voice.

Button Sound

This item is to set whether to have beep sound for pressing button.

Advance Setting

Advance setting is to change the important setup argument for the device. If the machines has administrator, only administrator can access this menu item. The submenu items under this includes default verification mode, verification interface, function key setting, summer time setting, firmware upgrade, restore factory default, delete all transaction and delete all enroll data.

Default Verification Mode

This item is to set the default verification mode. You can choose

FP

RF+FP

RF

ID+FP

ID+PWD

FP+PWD

RF+PWD

FP means fingerprint, RF means RFID card, ID means user ID. ID+FP means both user ID and fingerprint need to be verified before you can access.

Verification Interface

This menu item is for FP device with camera. We need to select whether to on the real time.

Capture of Photo

If we check this option, we need to input the percentage of photo captured by FP, card and password.

Real time photo capture	<input type="text"/>
FP photo	<input type="text"/>
Card photo	<input type="text"/>
PIN photo	<input type="text"/>

Display Photo

This menu item is for selection of displaying photo after successful verification.

Delete All Transaction

This menu item is to delete all the in out transactions in the machine. Before deletion, you are asked to confirm again for database security.

Delete all enroll data

This menu item is for deletion of all enroll data in the machine.

Restore Factory Default

This item is for restoring the setting of the device to the factory default. The action will not affect the enroll data and the existing in out transactions. Again, you are asked to confirm again for security.

Firmware Upgrade

This item is for upgrading of the machine firmware by USB disk or backend system. We will do the action when we have new function added or debug of the existing firmware.

Summer Time Setting

This setting is for summer nation that have summer time. You can make the device to have faster time starting from a date and have normal time after a end date.

Function Key Setting

The device has 4 function keys for setting different functions (F1 to F4). The default setting is

F1 = on duty

F2 = off duty

F3 = OT on

F4 = OT off

You can change the setting. For example, F1 can be changed to information inquiry.

F2 can be changed to bell.

Schedule Setting

It consists of a list of menu items for scheduling job. Scheduling job means a specified job will be invoked at a certain time. The list of menu items includes Power On, Power Off, Auto Sleep, Bell Setting, Idle Setting and Lock Auto Close.

Auto Power On

The power will be on at a certain time a day. Before power on, the machine is in sleep mode. For example, you can set the time of 07:00 for auto power on.

Auto Power Off

Auto power off is the opposite of auto power on. It is to preset a time for auto power off the machine. After off, you can switch on it by power button or the machine will be on by auto power on. When it is off, the machine is in sleep mode.

Bell Setting

You can set 8 times for the bell to sound (when). Besides, you can set the music for the bell (what) and the length for the sound (how long). The bell can be output to the internal speaker or to a external bell which requires independent power.

Idle Timeout Setting

This menu item is for setting the idle time for changing into other status. The default value is 0 which means disabled. If you set it to 1 minute, the machine will jump to another status. If no action within one minute, the device will jump to other pre-set state. The preset state can be sleep or switching off.

Close switch button


This menu item is to off the function of switch button. If it is off, you can only switch to the machine by unplug and plug power or auto power on.

Schedule status conversion

We can set each time period to have different status such as on duty, off duty, ot arrive, ot leave. You can have 6 times for setting status and the maximum status is 4.

Log Setting

Log Setting is to set the alert threshold for giving warning message in the device display. You can set 3 warning threshold. They are MLog Warning, GLog Warning and Reverify Time.



MLog Warning

Mlog Wrn means Management Log warning threshold. Management Log means the record for changing the menu items. It is to set the number of record space remaining for giving warning message. The default threshold is 100. That is, when the remaining space can only stores 100 records, the display will show warning message for you to download the management log records or to clear them.

GLog Warning

Glog Wrn means the general log warning threshold. General Log means the punch transaction. Each in represent one record and each out represent also one record. When the remaining space can store less than this figure, the display will show error message. You are supposed to download the transaction immediately or you will loss the previous punch records.

Reverify Time

This menu item is to set the number of seconds to prevent duplicate punch of the same user identifier. The default is zero. It means you can punch many times without control. It will waste the space of the device in storing useless records. So, customer can set this figure to a number of seconds. The maximum number of seconds allowed to be set is 255 seconds.

Comm Setting

The communication setting is mainly for management of communication between device and computer. It will set the parameters for the successful communication. It includes the baud rate, device ID, TCP/IP, RS232, RS485, CommPassword, DHCP and Manager PC IP Address

Baud rate

Baud rate is the parameter for both the RS232 and RS485 communication. The default rate is 115,200 bits per second. Normally, we will use this baud rate without the need for changing.

Device ID

Device ID is the unique identifier for each device in an environment. If you have more than one device in your network, you need to have unique device ID. If three devices in a network, we need to set those device ID to 1, 2 and 3 differently. Each device will have a default device id of 1.


TCP/IP

In this item, we can set the configuration related to the TCP/IP connection. We can set the IP address of the fingerprint device. The default IP address is 192.168.0.9. This is the identity of the fingerprint device in the network.

RS232


This item is to on/off the RS232 communication. The package of T8 includes a RS232 cable. The maximum distance for RS232 communication is 5 meters.

If your computer does not have com port, you can add a RS232-USB converter to connect with the USB port of the computer



The fingerprint device uses the D-type 9 pin socket for connecting the RS232 cable. The pin assignment is as follows.


Pin 2 = TX, Pin 3 = RX, Pin 5 = GND, Pin 1,4,6,7,8,9 = NC.




RS485

We can choose whether to on the RS485 communication. It has a maximum distance of 200 meters. Normally, we will use RS485 cable to connect between fingerprint device and computer. Also, we can use category 5 cable to replace RS485 cable as it is much more common.

Computer does not have RS485 communication protocol. It only has RS232 communication protocol. So, we need a converter to convert RS485 signal to RS232 signal.






The RS485 communication uses 3 wires. One is TX+. The second is TX-. The third is Ground.



RS485-to-RS232 converter

RS485 cable uses the same RJ45 socket for communication. The pin assignment is as follows:

Pin 5 = RS485A, Pin 6 = RS485B, Pin 1 = GND



CommPassword

We need a communication password for communication. It is to prevent other person to use the similar software to connect to the device. The default communication password is one zero (0).

DHCP

This is to on/off the Dynamic Host Control Protocol. DHCP is for assigning IP address to the device by DHCP host in the network.

Manager PC IP addr

This is the backend computer IP address. The computer will send arguments to the device for management of the time attendance machine. One example is to send the user message into the device.

Door Access Setting

Door Access is based on a set of time zones, a set of groups having these time zones and the assignment of time zones and groups to user. Each time zone has a list of open time by day of week., Sunday to Saturday. Each user can open door at any time from its group or its time zones. Their relationship is “or”. For example, if time zone 1 has

Sunday	08:00 – 19:00
Monday	08:00 – 19:00
Tuesday	08:00 – 19:00

Wednesday	08:00 – 19:00
Thursday	08:00 – 19:00
Friday	08:00 – 19:00
Saturday	08:00 – 19:00

Time zone 2 has

Sunday	21:00 – 23:00
Monday	21:00 – 23:00
Tuesday	21:00 – 23:00
Wednesday	21:00 – 23:00
Thursday	21:00 – 23:00
Friday	21:00 – 23:00
Saturday	21:00 – 23:00

User “John” has been assigned for both time zone 1 and time zone 2. So, John can open door from 08:00 to 19:00 and 21:00 to 23:00 every day. Besides, we can set 10 time match. Each time match consists of maximum of 3 groups. If you choose 2 groups, any user from the 2 groups must be punch together for successful access.

Time zone setting

It is to set the open door time range in a week. We can define a maximum of 50 time zones. You only need to input hour and minute. Time zone 1 allows open door by all time.

Sunday	00:00 – 23:59
Monday	00:00 – 23: 59
Tuesday	00:00 – 23: 59
Wednesday	00:00 – 23: 59
Thursday	00:00 – 23: 59
Friday	00:00 – 23: 59
Saturday	00:00 – 23: 59

Use <up> or <down> arrow to choose a time zone and press <ok> to go into day of week.

Time group setting

Totally, you can set up to 5 groups. For each group, you can assign maximum of 3 time zones to the group. After that, the group will have all the open time of its time zones. New user will have default group of group 1. Select the group by up/down arrow and input the time zone number (1 to 50).

Group Verification Mode Setting

In this item, you can set the device default verification mode. There are 8 verification mode.

- FP or RF or PWD
- FP
- RF and FP
- RF
- ID and FP
- ID and PWD
- FP and PWD

RF and PWD

User Door Access Setting

We can assign a list of door access parameter to each user.


User	000001
Group	1
Use Group Time zone	Yes
Time zone 1	1
Time zone 2	8
Time zone 3	40
Use Group Verification	Yes
Verify Mode	FP

The user can be assigned to a group so that the user will have the group time zone open time. If the argument “use group timezone” is set to “yes”, the 3 time zone number will be equal to the time zone number under the group.

For example, if user 0001 uses group time zone 3 group time zones 3 has time zones 7,8,9. Then, the 3 time zone numbers will be 7, 8, 9 correspondly. If we change the time zone number, the “use group time zone” will be changed to “no” automatically.

Time Match

We can select either “basic setting” or “group setting”. In basic setting, we just set number of user needed to open door. The default setting is 1. That is, when 1 user pass the verification, the door will be opened. You can set to maximum figure of 5. If you set it to 2, it means the door will be opened only if 2 users can pass the verification within 30 seconds.



The system will not care which group the 2 users belong to. Open door group allows a 1 to 3 groups combination for door access. We can have 10 open door group. For example, open door group 1 has combination of 1, 2 and 3. It means that any user for each group must pass the verification for door access.

Another example, open door group 2 has only group 4. Any member from group 4 can open the door.

Lock Control Time

Lock control time is the time between verification pass and the sending of signal to door lock adaptor.



The minimum unit is 0.5 seconds. The maximum value is 5 seconds. If it is set to 0, the door lock control will be closed.

Door Sensor Delay

Door sensor delay is the time between the door open and the checking of door sensor. If the door sensor status is different from the preset door status, alarm will be invoked. The unit for it is second.

Door sensor on/off setting

It consists of 3 types. They are none, always open and always close. None means we do not use door sensor on/off. Always open means if door is opened, lock should also be kept opened. If it is not the case, alarm will be invoked after the door sensor delay time. Always close means if door is closed, the lock should also be locked. Otherwise, alarm will be invoked after the door sensor delay time.

Duress Alarm Setting

If duress fingerprint is being punched, the alarm will be invoked after a period. This item is to prevent someone push the other to get access. Normally, a user will enroll 2 normal fingerprints and reserve one fingerprint as duress fingerprint. When he is forced to open door, he will use the duress fingerprint.

Power Checking Alarm

We can choose to on/off this alarm function.

Button Pressing Help

If we switch on this item, pressing down arrow “▼” for over 3 seconds will create help signal. If we press “ “ for over 3 seconds and then press fingerprint or input user ID, verified password will cause the duress alarm to be invoked. To off this item, just set it to false.

Alarm Delay

This menu item is for setting the delay time for auto alarm to be on. When duress signal happens, the alarm will not be on immediately. It will be on after this alarm delay time (0 to 255 seconds).

Wrong Punch Alarm

This is to set number of times in wrong punch for the alarm to be invoked. When the failure verification time reaches this figure, alarm will be invoked. Setting to zero means disabling this function. We can set this from 1 to 9 times. The default setting is 3 times.

Auto Checking

Sometimes, when you found the device has problem, you can use this menu item to troubleshoot the cause of the problem. Once the problem can be identified, you can solve it. This auto checking includes the testing of storage, LCD, voice, fingerprint sensor, keyboard and time. Please be reminded that the power should be kept stable in the power of checking. Otherwise, the hardware may be damaged, especially in the checking of storage.

USB Disk Management

This main item includes a list of menu items for setting up the device by USB disk. It includes

- Download enroll data
- Download management record
- Download user information
- Upload user information
- Upload message information
- Upload MP3

Download Enroll Data

It is to download the user enroll data into USB disk. A user ID may have several fingerprints and/or card and/or password. All these data will be downloaded too.

Download Management Record

It is to download the management setup record into the USB disk. Any change of the device setting will be recorded in the device and download to the USB disk.

Download User Information

It is to get the user manage from the device to USB disk. User message is the message displayed in the device for different user when she passes the verification.

Upload User Information

It is the opposite of downloading user information. It gets the file from USB disk back to the device.

Upload Message Transfer

This is to upload message for transferring.


Upload MP3

It is to upload the screen saver music and pictures from USB disk to the device.

(Message Remark: You can upload message from Uion Attendance Management System Software to machine through TCP/IP, RS232 and RS485 communication.)

Sys Info

This main item is for inquiry of information in the device. We have divided this information into 3 categories. They are memory, device information and advance inquiry.




Memory


It is to check the used and remain storage quantity of different arguments. These 2 figures are separated by a stroke “/”.

It includes

- Enroll count
- Fingerprint enroll
- Password enroll count
- Card enroll count
- GLog count
- MLog count
- Used space

Enroll count means the user enroll count. Fingerprint enroll means the fingerprint used and remaining quantities. Password enroll count is the enrolled password quantities. Card enroll count is the RFID card enrolled. GLog count is the general log (in/out transaction). MLog count is the management record count. Used space is the physical storage used and remained






Device Information

Device Information pinpoints the information in the device. It includes

- Factory production date
- Serial number
- Manufacturer
- Device management
- Device model
- Algorithm version
- Firmware version


Advanced Inquiry

It is for combination of input to create the query. It includes the GLog view, MLog view and Enroll View.



GLog view is the general log record inquiry (in/out transaction). MLog view is the management log record inquiry. Enroll view is the inquiry of enroll information for each user.

For each inquiry, you need to input the date range and user ID or user name.



Alarm reset

This menu item cannot be seen when there is no alarm signal. When there is alarm signal, you will see this menu item. Selecting this menu item will off the alarm.

***** The End *****